

# Installing NanoSim

---

Version A-2008.03-SP1, June 2008

**SYNOPSYS®**

# Copyright Notice and Proprietary Information

Copyright © 2008 Synopsys, Inc. All rights reserved. This software and documentation contain confidential and proprietary information that is the property of Synopsys, Inc. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Synopsys, Inc., or as expressly provided by the license agreement.

## Right to Copy Documentation

The license agreement with Synopsys permits licensee to make copies of the documentation for its internal use only. Each copy shall include all copyrights, trademarks, service marks, and proprietary rights notices, if any. Licensee must assign sequential numbers to all copies. These copies shall contain the following legend on the cover page:

“This document is duplicated with the permission of Synopsys, Inc., for the exclusive use of \_\_\_\_\_ and its employees. This is copy number \_\_\_\_\_.”

## Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

## Disclaimer

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

## Registered Trademarks (®)

Synopsys, AMPS, Cadabra, CATS, CRITIC, Design Compiler, DesignWare, Formality, HSPICE, iN-Phase, Leda, MAST, ModelTools, NanoSim, OpenVera, PathMill, Photolynx, Physical Compiler, PrimeTime, SiVL, SNUG, SolvNet, TetraMAX, VCS, Vera, and YIELDirector are registered trademarks of Synopsys, Inc.

## Trademarks (™)

AFGen, Apollo, Astro, Astro-Rail, Astro-Xtalk, Aurora, AvanWaves, Columbia, Columbia-CE, Cosmos, CosmosEnterprise, CosmosLE, CosmosScope, CosmosSE, CSim, DC Expert, DC Professional, DC Ultra, Design Analyzer, DesignPower, Design Vision, DesignerHDL, Direct Silicon Access, Discovery, Encore, EPIC, Galaxy, HANEX, HDL Compiler, Hercules, Hierarchical Optimization Technology, HSIM, HSIM<sup>plus</sup>, HSPICE-Link, in-Sync, iN-Tandem, i-Virtual Stepper, Jupiter, Jupiter-DP, JupiterXT, JupiterXT-ASIC, Liberty, Libra-Passport, Library Compiler, Magellan, Mars, Mars-Rail, Milkyway, ModelSource, Module Compiler, Planet, Planet-PL, Polaris, Power Compiler, Raphael, Raphael-NES, Saturn, Scirocco, Scirocco-i, Star-RCXT, Star-SimXT, System Compiler, Taurus, TSUPREM-4, VCS Express, VCSi, VHDL Compiler, VirSim, and VMC are trademarks of Synopsys, Inc.

## Service Marks (SM)

MAP-in, SVP Café, and TAP-in are service marks of Synopsys, Inc.

SystemC is a trademark of the Open SystemC Initiative and is used under license.

ARM and AMBA are registered trademarks of ARM Limited.

Saber is a registered trademark of SabreMark Limited Partnership and is used under license.

All other product or company names may be trademarks of their respective owners.

Printed in the U.S.A.

Installing NanoSim, A-2008.03-SP1

# Installing NanoSim

---

This document describes how to install the NanoSim product.

This document contains the following sections:

- [Media Availability and Supported Platforms](#)
- [Disk Space and Memory Requirements](#)
- [Installing the Software](#)
- [Setting Up the User Environment](#)
- [Setting Up the Discovery AMS Simulation Interface \(SimIF\)](#)
- [Verifying the NanoSim Installation](#)

To ensure a successful installation, Create the Synopsys root directory (see *Installing Synopsys Tools*, available at <http://www.synopsys.com/install>) before beginning the installation process.

---

## Media Availability and Supported Platforms

NanoSim is available on CD or by EST download. Obtain the appropriate binary executable files based on the operating system you need. Table 1 shows the supported platforms for the version A-2008.03-SP1 release (including ADFMI, NanoSim Integration with VCS, nWave, and Verilog-A).

*Table 1 Supported Platforms and Keywords*

---

<b>Platform</b>	<b>Operating system</b>	<b>Synopsys platform keyword</b>
AMD Opteron	Red Hat Enterprise Linux v4, v5 <sup>1</sup>	amd64 (64-bit mode) linux (32-bit mode) <sup>2</sup>
EMT64T	SUSE Enterprise Linux 9, 10 <sup>1</sup>	suse64 (64-bit mode) suse32 (32-bit mode)

---

## Installing NanoSim

### Disk Space and Memory Requirements

Table 1 Supported Platforms and Keywords (Continued)

Platform	Operating system	Synopsys platform keyword
IA-32 (X86)	Red Hat Enterprise Linux v4, 5 <sup>1</sup>	linux (32-bit mode) <sup>2</sup>
IBM RS/6000	AIX 5.3	rs6000 (32-bit mode) aix64 (64-bit mode)
Sun SPARC	Solaris 9, 10 <sup>1</sup>	sparcOS5 (32-bit mode) sparc64 (64-bit mode)

1. Binary-compatible hardware platform or operating system. Note, however, that binary compatibility is not guaranteed.

2. The 32-bit (x86) Linux software is binary compatible with Intel EM64T or AMD Opteron running Red Hat Enterprise Linux. Note, however, that binary compatibility is not guaranteed.

## Disk Space and Memory Requirements

The NanoSim tool has the following minimum memory requirements:

- Physical Memory – 512 MB (1GB is recommended)
- Swap space – 512 MB (2GB are recommended)

The disk space requirement varies, depending on the platform and tool selected for installation. During the installation process, Synopsys Installer displays the required disk space.

## Accessing Memory Beyond 2 GB With 32-Bit Tools

In general, UNIX-based systems support a maximum memory of 2 GB for 32-bit processes. However, the NanoSim tool can extend memory beyond 2 GB.

### Note:

Available memory is space not used by the OS, the windowing system, or other applications.

To access memory beyond 2 GB,

1. Make sure your server has Solaris 9 (or later) loaded.
2. Make sure your server has at least 4 GB of memory (physical and swap space) available.

**Note:**

Physical memory equals data size plus stack size, but stack size is used before data size. Therefore, setting stack size to a large value causes problems for designs that need to go over 2 GB. If you set the stack size too high, you cannot get enough memory for your data. To check the settings, use the `limit` command at the system prompt. For more information, see [Installing Synopsys Tools](#).

3. Make sure the system you are using does not have restrictions that prevent you from using more than 2 GB of memory.
4. Create unlimited data size in the shell that you are using: C, Bourne, Korn, or Bash. If there are system-wide limits on the data size you can create, you can remove them or override them. You can do this in one of two ways:
  - Enter one of the following commands:
    - For the C shell,  

```
% limit datasize 3800000
```
    - For the Bourne, Korn, or Bash shell,  

```
# ulimit -s -d 3800000
```
  - Modify the kernel of your server. This approach allows everyone using your server to extend memory beyond 2 GB.

---

## Installing the Software

NanoSim uses the Synopsys Installer tool, which allows you to use a graphical user interface (GUI) or a text script. For information about downloading the Synopsys Installer and NanoSim, see [Installing Synopsys Tools](#).

To install NanoSim by EST or from the CD, follow the procedures described in [Installing Synopsys Tools](#).

[Installing Synopsys Tools](#) shows an example Synopsys media installation script for the synthesis tools. NanoSim is installed in a similar manner.

NanoSim is a stand-alone product and cannot be installed over an existing Synopsys product, including a prior version of NanoSim. You must create a new directory for NanoSim.

The NanoSim ADFMI, Verilog-A, and NanoSim-VCS features, and the nWave waveform viewer are automatically installed with the NanoSim installation.

## Installing NanoSim

### Setting Up the User Environment

However, you must install the Discovery AMS Simulation Interface (SimIF) tool stand-alone in a new empty directory.

Download instructions for the Discovery AMS Simulation Interface (SimIF) are included with the NanoSim EST download instructions.

---

## Setting Up the User Environment

To set up the user environment, you must specify the location of the executable file and set the license environment variable.

---

### Specifying the Executable File Location

The approach you take will depend on the shell you are using.

To set up a new NanoSim tool user,

- If you are using the C shell, source the CSHRC\_ns file located in the install directory.

```
% source install_dir/CSHRC_ns
```

The CSHRC\_ns file sets the path for NanoSim and the NanoSim man pages, as follows:

```
set path=(install_dir/bin $path)
setenv MANPATH install_dir/doc/ns/man:$MANPATH
```

where *install\_dir* is the directory where the tool has been installed.

The default executable is NanoSim 32-bit. To run the NanoSim 64-bit executable, set the NANOSIM\_64 environment variable before launching NanoSim:

```
setenv NANOSIM_64 1
```

- If you are using the Bourne, Korn, or Bash shell, add the following lines to the .profile, .kshrc, or .bashrc file:

```
PATH=install_dir/bin:$PATH
export PATH
MANPATH=install_dir
```

## Setting the SNPSLMD\_LICENSE\_FILE Environment Variable

You must install the SCL software and define the `SNPSLMD_LICENSE_FILE` variable before you can verify the NanoSim installation.

For information about downloading and installing SCL and on setting the license variable, see [Installing Synopsys Tools](#).

---

## Setting Up the Discovery AMS Simulation Interface (SimIF)

To set up a new Discovery AMS Simulation Interface (SimIF) user,

- If you are using the C shell, source the `CSHRC_simif` file located in the install directory.

```
% source install_dir/CSHRC_simif
```

The `CSHRC_simif` file sets the path for Discovery AMS Simulation Interface as follows:

```
setenv SNPS_SIMIF install_dir  
set path=(${SNPS_SIMIF}/bin $path)
```

where `install_dir` is the directory where the tool has been installed.

If you do not source the `CSHRC_simif` file, copy the preceding line and set the path from that file.

- If you are using the Bourne, Korn, or Bash shell, add the following line to the `.profile`, `.kshrc`, or `.bashrc` file:

```
SNPS_SIMIF=install_dir  
export SNPS_SIMIF  
  
PATH=${SNPS_SIMIF}/bin:$PATH  
export PATH
```

## Installing NanoSim

Verifying the NanoSim Installation

---

### Verifying the NanoSim Installation

To verify the NanoSim or the Discovery AMS Simulation Interface installation,

1. Make sure you are in a directory where you have read/write privileges.

```
% cd $HOME
```

2. Invoke Nanosim by entering

```
% nanosim
```

If you see information about the product version, production date, and copyright, the installation was successful.

3. Invoke the Discovery AMS Simulation Interface tool by entering

```
% simif
```

If you see the Discovery AMS Simulation Interface window, the installation was successful.